


# Operation and Maintenance Manual



**Version: EN**

**Edition: 2019-01**

**Part Number: 0404-830 (US)**

**Valid From Serial No: 00500 (RT-25)**

**Original Instructions**

**RT-25**

**For the Engine Operation & Maintenance Manual, access the web at: <https://www.perkins.com>**

**Select “Operation and maintenance manuals” under the “Parts and Service” heading at the bottom of the page.**

**Locate the engine family type and code (first two digits of your engine serial number) on the engine data plate.**

**Once identified, select them from the list, then choose the required language to access your engine manual.**

**Please fill in before commissioning the machine:**

**Model:** \_\_\_\_\_

**Vehicle Serial Number:** \_\_\_\_\_

**Year of Manufacture:** \_\_\_\_\_

**Commissioned on:** \_\_\_\_\_

**Dealer:**

--



The operator must read and understand all the instructions in this manual before operating the RT-25.

	Page
Introduction .....	2
Safety .....	5
Technical Data .....	29
Machine Description / Controls.....	35
Operation.....	45
Transportation.....	55
Maintenance .....	61
Proposition 65 .....	82

# 1 INTRODUCTION

---

## 1.1 Product Identification (PIN)

The machine PIN is located on the identification plate, behind and to the left of the operator seat.

Please state the model of the machine and PIN when making inquiries in regards to parts, service, or warranty.

## 1.2 Introduction

**Thank you for purchasing an RT-25 Compact Track Loader.** We are confident that the machine you have chosen will provide excellent performance and efficient operation.

The information contained in this manual is intended to provide the operator with all necessary information for the proper use of the machine.

It is imperative that this manual be provided to the end user at the time of purchase, prior to operation and kept with the machine at all times. If lost or damaged, contact your dealer immediately to obtain a replacement prior to resuming operation.

**The operator is responsible for the safe operation of the machine.**

**The operator must read, understand and obey the instructions in both this and the AEM safety manual for skid steer and compact track loaders prior to operating or performing maintenance or service on the machine.**

Should you need clarification or further explanation of the topics in this manual, please contact your dealer immediately for assistance.

Information describing special equipment or attachments and their operation are not included in this manual.

This manual should be stored in the provided storage location in the cab enclosure to protect it from the elements.



## 1.3 Safety Alert Symbol

The safety alert symbol is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

## 1.4 Intended Use

The RT-25 with bucket attachment is intended to be used solely for work consistent with its design. Such work involves loosening, collecting, transporting, and distributing soil, rock, or similar materials as well as loading these materials onto trucks, conveyors, or other methods of transport.

After installation of compatible (see section 4.8) special working attachments, the equipment can be used for corresponding applications.

The operator must follow the operating instructions for any externally supplied components or attachments.

Any use varying from that described here or any lack of adherence to the operating instructions, maintenance procedures, or replacement intervals described in this manual shall be regarded as unintended or improper use. The supplier cannot be held responsible for any damage resulting from improper use. This risk is borne solely by the user.

## 1.5 Bulletin Compliance

It is very important to comply with all safety related bulletins. Bulletins are tied to the most current owner on record. Therefore, it is important that any new owner contact their local dealer to register the machine in their name. This will ensure that they will be notified in the event of a safety related bulletin affecting their machine.

## 1.6 Contacting the Manufacturer

If you have questions relating to ownership including, but not limited to: accident reporting, current owner updates, product applications and safety, standards and regulations compliance, product modifications, transfer of ownership, please consult your local dealer as the first point of contact.

## 1.7 Copyright

This manual is intended for use by personnel responsible for operation, maintenance, repair, and supervision activities involving the machine described within.

This manual is copyrighted. It shall not, either in whole or in part, be reproduced, transmitted, or used for the purpose of competition without our prior written consent.

# **1 INTRODUCTION**

---

## **1.8 Warranty**

Your RT-25 is warranted under the Standard Limited New Product Warranty (“Warranty”). A copy of the Warranty certificate is available from your Authorized RT-25 Distributor.

	Page
2.1 Safety Alert System .....	7
2.2 Graphical Symbols.....	8
2.3 Safety Signs (ISO) .....	12
2.4 General Notes.....	14
2.5 Personal Protection Equipment .....	15
2.6 Hazard Zone.....	15
2.7 Operation.....	16
2.8 Stability.....	17
2.9 Transport of Persons .....	17
2.10 Fire Prevention .....	18
2.11 Crush / Burn Avoidance .....	19
2.12 Placing Into Operation .....	20
2.13 Starting the Machine .....	20
2.14 Jobsite Safety.....	21
2.15 Parking the Machine .....	22
2.16 Towing / Retrieving.....	22
2.17 Transporting .....	23
2.18 Maintenance .....	24
2.19 Battery .....	26
2.20 Hydraulic Hoses / Lines .....	27

This Page Intentionally Left Blank



### 2.1 Safety Alert System

#### Safety Alert Symbol

This symbol means: **Attention! Be alert! Your safety is involved!**



The safety alert symbol is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

This symbol is used as an attention-getting device throughout this manual as well as on decals and labels fixed to the machinery to assist in potential hazard recognition and prevention.









Property or equipment damage warnings in this publication are identified by the signal word "NOTICE".











#### NOTICE

**"NOTICE" Indicates a hazardous situation which, if not avoided, could result in property or equipment damage.**











## 2 SAFETY









### 2.2 Graphical Symbols

Hazard Pictorial	Avoidance Pictorial	Description
		<p><b>Hazard:</b> Skin/Oil Injection</p> <p><b>Avoidance:</b></p> <ul style="list-style-type: none"> <li>• Relieve internal pressure before disconnecting any line or fitting.</li> <li>• Keep away from leaks or pin-holes.</li> <li>• Use cardboard to check for leaks.</li> </ul> <p>Fluid injected into skin must be surgically removed within a few hours by a doctor familiar with this type of injury or gangrene will result.</p>
		<p><b>Hazard:</b> Corrosive</p> <p><b>Avoidance:</b> Read and understand the operator's manual.</p>
		<p><b>Hazard:</b> Entanglement</p> <p><b>Avoidance:</b> Stop machine and remove key before servicing.</p>
		<p><b>Hazard:</b> Burn/Scald</p> <p><b>Avoidance:</b> Allow to cool before opening.</p>

Hazard Pictorial	Avoidance Pictorial	Description
		<p><b>Hazard:</b> Explosion/Burn</p> <p><b>Avoidance:</b></p> <ul style="list-style-type: none"> <li>• Keep all flames/sparks away!</li> <li>• No Smoking!</li> <li>• Read and understand all manuals.</li> </ul>
		<p><b>Hazard:</b> Fall</p> <p><b>Avoidance:</b> Use the provided access system when entering or exiting the machine.</p>
		<p><b>Hazard:</b> Fall</p> <p><b>Avoidance:</b> No Riders.</p>
		<p><b>Hazard:</b> Burn</p> <p><b>Avoidance:</b> Do not touch hot surfaces.</p>
		<p><b>Hazard:</b> Crush</p> <p><b>Avoidance:</b> Fasten seat belt.</p>

## 2 SAFETY


Hazard Pictorial	Avoidance Pictorial	Description
		<p><b>Hazard:</b> Entanglement</p> <p><b>Avoidance:</b> Stop machine and remove key before servicing.</p>
		<p><b>Hazard:</b> Rollover / Ejection</p> <p><b>Avoidance:</b> Carry loads low, keep heaviest end of machine uphill at all times while operating on inclines.</p>
		<p><b>Hazard:</b> Fall</p> <p><b>Avoidance:</b> Do not use the bucket or attachment as a work platform.</p>
		<p><b>Hazard:</b> Crush</p> <p><b>Avoidance:</b> Stay clear of moving machine.</p>
		<p><b>Hazard:</b> Crush</p> <p><b>Avoidance:</b> Keep clear of lift arms and attachments.</p>

Hazard Pictorial	Avoidance Pictorial	Description
		<p><b>Hazard:</b> Crush</p> <p><b>Avoidance:</b> Install lift arm brace prior to servicing.</p>
		<p><b>Hazard:</b> The safety alert symbol is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.</p> <p><b>Avoidance:</b> Read and understand the operator's manual.</p>
		<p><b>Hazard:</b> Fire</p> <p><b>Avoidance:</b> Read and understand the operator's manual.</p>
		<p><b>Hazard:</b> Explosion / Burn</p> <p><b>Avoidance:</b> No smoking. Keep all open flames and sparks away. Stop engine before adding fuel.</p>

## 2 SAFETY

### 2.3 ISO Safety Signs

The safety signs are located in/on the machine as indicated. (Descriptions of the symbols are provided in section 2.2)




#### Key

1. Fall hazard
2. Crush / rollover hazards (inside cab enclosure)
3. Fall hazards / read operator's manual (inside cab enclosure)
4. Proposition 65 warning
5. Read operator's manual (inside cab enclosure)
6. Skin (oil) injection hazard
7. Explosion / burn hazard (read operator's manual)
8. Crush hazard (run over)
9. Crush hazard (lift arm brace)
10. Crush hazard (lift arms)
11. Tie down locations (on chassis, beneath lift arm)
12. Fire hazard (read operator's manual) (inside cab enclosure)

### Note:

Safety signs are designed and fitted to the product to warn of possible dangers, and **MUST** be replaced immediately if they become unreadable or lost. If the product is repaired and parts have been replaced on which safety signs were fixed, be sure new safety signs are fitted before the product is put into service.



### Key (continued)

- 13. Burn/Scald hazard (engine compartment)
- 14. Emergency Exit (rear window / if equipped).
- 15. Emergency Exit (front door / if equipped).
- 16. Skin (oil) injection hazard
- 17. Crush hazard (lift arm brace)
- 18. Crush Hazard (Lift arms)
- 19. Crush hazard (run over)
- 20. Clean undercarriages notice (one on each side of the machine)
- 21. Burn hazard (engine compartment)
- 22. Explosion / burn hazard (read operator's manual) (engine compartment)
- 23. Entanglement hazard (engine compartment)

## 2 SAFETY

---



### 2.4 General Safety Notes

- It is the responsibility of the operator to be aware of his/her surroundings at all times. **Keep a safe distance from bystanders at all times during operation. Always look in the direction of travel.**
- Read and understand all safety signs, the operator's manual and the AEM safety manual for this type of equipment prior to operation.
- If safety signs are obstructed by dirt or debris, clean them using mild soap and water prior to operation. **DO NOT** use solvent based cleaners, as they may damage the safety sign material.
- If safety signs are damaged or illegible, replace them immediately, prior to operation.
- Never jump off of the machine. Instead use the hand holds and step designed for entering and exiting the machine. Face the machine and use three points of contact (defined as: one foot and two hands, or one hand and two feet) to ensure your safety.
- Ensure the access system (step and handholds) are clean prior to entering or exiting the machine.
- Do not use any method of operation, inspection, or maintenance that may impair safety.
- This machine is only to be used when properly equipped for the task to be performed and when properly inspected and maintained to ensure safe operation.
- The manufacturer's instructions regarding operation, inspection, maintenance, repair and transportation **must** be followed.
- Never place the machine into operation without having first performed a thorough walk-around inspection and making any necessary repairs or adjustments.
- Safety devices on the machine shall not be deactivated or removed.
- Do not make any changes, additions or conversions to the machine that could have a negative effect on safety without the manufacturer's written approval.
- It is the responsibility of the operator to communicate intentions for work (machine movement) to anyone standing or working nearby, prior to operation.





### 2.5 Personal Protection Equipment (PPE)

The machine is designed to accommodate and protect an operator during operation from foreseeable injury **when used as intended and when equipped properly for the task(s) being performed**. Operators should not wear rings, scarves, open jackets, and should ensure that all clothing is tightly secured. Long hair should be restrained. Personal Protective Equipment (PPE) must be worn in the absence of an enclosed cab. In this case PPE would include, but not be limited to, safety glasses. The use of some attachments may require additional PPE, such as hearing protection, hardhat, gloves, and steel-toed shoes. In some applications high visibility/reflective jackets are required.

Personal protection equipment is also recommended when performing maintenance or service on a machine. Always wear appropriate protective equipment for working conditions when working on or around the machine. Loose clothing should not be worn and long hair should be restrained. Wear hard hats, protective face/eyewear, safety shoes and any other equipment necessary to ensure your safety and the safety of others around you as you work.



### 2.6 Hazard Zone

The hazard zone encompasses the area around the machine in which persons may be injured by movements of the machine during operation, its attachments, or by falling loads.

Do not position yourself or allow anyone else within this hazard zone during machine operation. Keep a safe distance to ensure your safety while the machine is in operation.

If someone enters the hazard zone, the operator must stop all work and give a warning signal to the person who may be in danger to leave the hazard zone. Work should not resume until all persons have vacated the hazard zone.

To minimize the possibility of a crushing hazard, a safe, sufficient distance (min. 0.5 m (1.6 ft)) must be kept from solid objects, e. g. buildings, slopes, scaffolding, other machines, etc. If that distance cannot be kept, fence off the area between solid construction elements and the working range of the machine.

If conditions are such that the machine operator's view of the driving and working zone is restricted, he must be guided or the driving and working zone must be secured by means of a solid barricade.

## 2 SAFETY

---



### 2.7 Operation

Earth moving machines are only to be operated and serviced by individuals who:

- are physically and mentally able to operate and / or service the machine in a safe and effective manner (not impaired in any way).
- have been instructed in the proper operation or maintenance of the machine and have demonstrated competence in these areas.
- can be trusted to perform their assigned duties in a safe and reliable manner.
- are of the legal minimum age for performing such duties.

It is the responsibility of the operator to:

- read, understand and obey the instructions in this manual and the AEM safety manual for skid steer and compact track loaders.
- maintain a safe distance from bystanders at all times and always look in the direction of travel.
- use the machine in accordance with its intended use (section 1.4).
- inspect the machine prior to operation and perform any necessary checks, adjustments or repairs to ensure safe operation.
- familiarize him/herself with the local jobsite conditions and immediately remedy any fault that may compromise safety.
- use the machine in accordance with the appropriate local jobsite organization system to ensure safe coordination with other machines, vehicles, and people on the jobsite.

Investigate any jobsite prior to operation to determine whether any special hazards exist. Take necessary measures to eliminate or reduce any hazard.

**Do not operate the machine in unsafe conditions including, but not limited to:** in inclement weather (example: electrical storm), near overhead electric lines, in enclosed areas without proper ventilation, in contaminated areas without necessary safety equipment and personnel.

Turning the key to the off position while the machine is in motion (as described below) should be done only in an emergency. If done, **the machine will stop abruptly.**

**To stop all machine movement in case of emergency:**

- Turn the ignition key to the off position (item 8, section 4.1).



### 2.8 Stability

The machine must always be operated with caution in order to maximize machine stability and guard against the possibility of a rollover.

- Travel only at speeds appropriate for the local conditions.
- Do not exceed the operating capacity of the machine.
- Exercise extreme caution while operating on inclines.
- Avoid operation on steep inclines.
- Do not make sudden changes in direction, move slowly, and always carry loads low to maximize machine stability.
- Always keep the heaviest end of the machine facing uphill when travelling on an incline.
- When operating on any surface other than firm and level ground, use extra caution. Decrease work speeds, limit load size and make any other necessary adjustments to maximize your safety and that of others in the work area.



### 2.9 Transporting Persons

- The machine must not be used to transport persons.

## 2 SAFETY

---



### 2.10 Fire Prevention

Compact Track loaders have components that operate at high temperatures. It is important to observe all inspection, operation and maintenance guidelines to minimize the possibility of fire.

- Turn the engine off when refueling.
- When refueling or charging the battery, do not smoke or allow open flame near the machine.
- Always start the engine according to the procedure in the operating instructions.
- Inspect and clean the radiator/oil cooler, engine compartment, exhaust system and other areas where there may be hot or rotating parts **daily (or as needed)**. In some work environments, flammable debris including but not limited to: leaves, straw, wood particles (dust), and similar items can accumulate in these areas and can lead to fire.
- Check the electrical system regularly. Have any faults such as loose connections, burnt fuses, glow lamps and damaged wiring repaired by professional personnel immediately.
- Regularly check all lines, hoses and threaded couplings for leaks and damage. Repair leaks immediately and replace any defective parts. Oil leaks can easily lead to a fire. **NEVER use bare hands to check for hydraulic leaks!** Pressurized fluid (oil) can penetrate skin and cause gangrene. If injection occurs, seek medical attention immediately!
- Do not use any starting aids containing ether to start diesel engines with pre-heat systems! Use of starting aids of this nature can cause an EXPLOSION!
- Familiarize yourself with the location of fire extinguishers (if equipped) in/on the machine and how to use them as well as local options for reporting and fighting fires should one occur.

### Fuel Handling Precautions

- Do not smoke or allow open flame near fueling operations.
- Always maintain control of the fuel filter nozzle when filling the tank.
- Do not fill the fuel tank to capacity, allow room for expansion.
- Clean up fuel spills immediately.
- Tighten the fuel tank cap securely. Should the cap become lost or damaged, replace it immediately with the original manufacturer's recommended replacement cap to ensure proper venting and function.
- Never use fuel for cleaning purposes.
- Always use the correct fuel grade for the operating season.

**Ultra Low Sulfur Diesel (ULSD)** poses a greater static ignition hazard than earlier diesel formulations with higher Sulfur content. Avoid death or serious injury from fire or explosion; consult with your fuel or fuel system supplier to ensure the delivery system is in compliance with fueling standards for proper grounding and bonding practices.



### **2.11 Crush and Burn Avoidance**

- Do not work under the lift arms unless they are resting safely on the ground or supported by the lift arm brace.
- Keep your entire body inside the operator enclosure at all times during operation. Never work with any part of your body protruding from the cab.
- Do not use any restraining devices such as cables or chains that are damaged or do not have sufficient carrying capacity. Always wear safety gloves when working with wire cables.
- In adverse conditions (high winds, uneven terrain, etc.), keep clear of (or secure against unintended movement) raised or open hinged items (hoods, doors, engine enclosure panels and similar).
- Never align holes with your fingers when working on the machine. Instead use a suitable mandrel.
- Keep yourself and all objects that could be drawn into the fan at a safe distance while the engine is running.
- The entire cooling system is hot and under pressure when it is at or near operating temperature. Avoid touching parts that carry coolant to avoid the possibility of burns.
- Allow the machine to cool thoroughly prior to touching or removing the cooling system cap. Once cool, loosen the cover slowly to bleed off any excess pressure.
- The engine and hydraulic oil are hot when at or near operating temperature. Avoid skin contact with hot oil or parts carrying oil.
- Wear safety goggles and protective gloves when you are working with the battery. Keep sparks and open flames away from the work area.
- Exhaust components are hot when at or near operating temperature. Allow the machine to cool thoroughly prior to touching or performing service work on exhaust components to avoid the possibility of burns.

## 2 SAFETY

---



### 2.12 Placing into Operation

- Every time before placing the machine into operation, perform a thorough walk-around inspection of the machine.
- Check the machine for loose pins, cracks, tears, wear, leaks and deliberate damage.
- Never place a damaged machine into operation.
- Make any necessary repairs immediately, prior to resuming operation.
- Inspect to make sure all warning signs are in place and legible, then close and latch all hoods and covers.
- Make sure all windows and mirrors (if equipped) are clean. Secure door and windows against unintentional movements.
- If visibility is reduced by a lack of window or screen / lens clarity (yellowing, scratches, damage, etc) replace affected components prior to operating.
- Make certain no one is working on or under the machine and warn any persons standing nearby that the machine will be placed into operation.
- Prior to placing the machine into operation, adjust the driver's seat, mirrors (if equipped), and ventilation system settings (if equipped) so you can work in comfort and safety.



### 2.13 Starting the Machine

- Before starting, check all indicator lamps and instruments to make certain they are working properly.
- Start the engine in the manner described in the operating instructions.
- Only allow the engine to run in enclosed rooms if there is adequate ventilation. If necessary, open doors and windows to ensure a proper supply of fresh air.
- Bring the engine and hydraulic oil up to operating temperature. Low oil temperatures can cause the control system to respond sluggishly.
- Move the machine carefully to open ground and then check the functionality of the lift arm and drive controls as well as the lighting equipment.



### 2.14 Jobsite Safety

- Before beginning work, become acquainted with any special features or requirements of the jobsite. These may include, for example, obstructions in the work area, the carrying capacity of the ground and requirements to close the jobsite off from public traffic.
- Always maintain a safe distance from bystanders, overhanging features, edges, embankments and unsafe surfaces.
- Be especially cautious if visibility is poor, light conditions are low or soil conditions vary.
- Become acquainted with the location of supply lines at the jobsite and be especially careful when working close to them. Consult appropriate local authorities for necessary information regarding any such lines prior to commencing work.
- Keep the machine at an adequate distance from overhead electrical lines. When working in the vicinity of overhead electrical lines, do not come close to the lines with the machine. **Injury or death may result!** If possible, have the current turned off or line re-routed prior to beginning work.
- In the event electrical current jumps from a line to the machine, follow these rules:
  - do not perform any movements with the machine
  - do not leave the cab
  - warn persons outside not to approach or touch the machine
  - have the current turned off immediately
- Always turn on the appropriate lighting when visibility is poor or light conditions are low.
- Do not allow any passengers in or on the machine.
- Stay seated with the seat belt fastened while working.
- Report any operating faults immediately. Make sure any necessary repairs are performed prior to resuming operation.
- Never leave the machine unattended with the engine running.

## 2 SAFETY

---



### 2.15 Parking the Machine

- Stop the machine only on an even and solid surface.
- Lower the lift arms to the frame stop and rest the bucket on the ground.
- Shut the machine down as described in section 5.12.
- Close the machine doors and windows (if equipped), remove the key to secure the machine against unauthorized use.



### 2.16 Towing/Retrieving the Machine

- Always observe the correct procedure as described in the operating instructions.
- The machine should be towed only in exceptional cases, for example to bring the machine away from an endangered place for repair.
- Towing equipment such as chains, cables, etc., must be of the correct capacity and must use both of the multi-purpose tie town locations on the rear of the chassis.
- Pull the chains taut slowly and carefully. A sudden jerk can cause sagging chains or cables to tear or snap.





### 2.17 Transporting the Machine

- Use only suitable transport and lifting equipment with sufficient carrying capacity.
- Load the machine on firm and level ground.
- Before driving onto the ramps, clean them and the machine tracks of any materials that may cause slippage (snow, ice, water, mud, sludge, oil, etc.).
- Properly align the machine with the loading ramp.
- Have a guide give the machine operator any necessary signs to maximize safety during loading.
- Back the machine carefully up the ramps and onto the transport vehicle.

---

**Note:** The heaviest end of the machine should remain uphill when operating on an incline. Always back the machine onto the transport vehicle unless fitted with a heavy attachment or loaded bucket.

---

- Before you leave the machine, relieve all residual pressure by making sure all operating levers and switches are in their neutral positions. Remove the ignition key.
- Secure the door, windows and hood on the machine.
- Secure the machine and any other items against slipping with chains, ropes of the proper capacity.
- Before departure, investigate the route to be taken, especially in regard to limits for width, height and weight.
- Pay close attention when driving under electrical lines, bridges, or through tunnels.
- Use the same caution when unloading as for loading. Remove all cables/chains. Start the engine as described in the operating instructions. Carefully drive down the ramp from the transport vehicle using a guide if necessary to direct movement.
- When lifting attachments or components, use caution. Attach straps or chains securely and in such a way that they evenly distribute the weight of the item to be lifted, ensuring a balanced load. Stay clear of expected travel path.

## 2 SAFETY

---



### 2.18 Maintenance

- Do not perform any maintenance work or repair task that you do not understand thoroughly.
- Park the machine on firm and level ground in a well lit and well ventilated area suitable for performing service or maintenance work.
- Disconnect the battery (always disconnect the negative cable first and reconnect last) and remove the ignition key from the ignition before beginning work on a machine. Place a **Do Not Operate** tag across the opening of the cab to alert any operator that maintenance is in progress.
- Do not work on or under any machine that is supported only by a hydraulic jack or hoist. Always use suitable mechanical supports to ensure that the machine will not fall.
- Make sure the work area around the machine is safe and make yourself aware of any hazardous conditions that may exist. If the engine needs to be started inside an enclosure, make sure that the engine's exhaust is properly vented.
- Be sure all protective devices including guards and shields are properly installed and functioning correctly before beginning any service task. If a guard or shield must be removed to perform the maintenance work, use extra caution.
- Always use the appropriate tools for the work to be performed. Tools should be in good condition and you should understand how to use them properly before performing any task.
- When replacing parts or fasteners, use parts of equivalent quality, grade and/or size. Use original equipment components to ensure the proper form, fit, and function of replacement parts.
- When performing maintenance work, always wear appropriate safety clothing for the task to be performed. Some examples might include: safety shoes, safety goggles and safety gloves.
- When performing service that requires the lift arms to be in the raised position, always utilize the lift arm brace.
- If safety equipment needs to be dismantled to fit equipment or perform maintenance or repairs, it must be reattached and tested immediately after the maintenance and repair jobs are completed.

- Clean the machine prior to beginning work. Clean especially the connections and screw couplings of oil, fuel and upkeep materials at the beginning of the maintenance/repair job.
- Do not use flammable liquids to clean the machine.
- Perform tasks on the machine that involve welding or grinding only if approved by the manufacturer. Clean the machine and the work area of dust and any combustible materials before welding or grinding to avoid fire or explosion.
- Before cleaning the machine with water jets (high pressure cleaner) or other cleaning agents, cover or seal over all openings in which water or cleaning agents should not penetrate for safety and/or functional reasons. Electrical motors, switch panels and plug connections are especially subject to damage. Before cleaning, inspect all fuel, engine oil and hydraulic oil lines for leaks, loose connections, rubbed spots and damage. Repair or replace any damaged components immediately.
- When working with oils, greases and other chemical substances, observe all safety requirements that apply to the product in question.
- Ensure that fuels, lubricants and coolants as well as replaced parts are disposed of in an environmentally proper manner.
- Proceed carefully when working with hot lubricants, coolants and fuels (danger of burns and scalding).

### **Relieve Hydraulic System Pressure**

Prior to attempting any hydraulic maintenance or repair, relieve hydraulic system pressure by performing the following:

1. Remove any attachment, then shut the machine down as described in section 5.12 of this manual.  
**Note:** When lowering the lift arms, lower them to the frame stops (or onto the lift arm brace if the lift arms are to remain up for service). Fully curl the quick attach (or you can extend it to the ground if the loader is down), then activate the float function (section 4.3.1 of this manual) momentarily to ensure there is no pressure left in the lift arm circuit.
2. Turn the continuous auxiliary hydraulic switch off and ensure the intermittent auxiliary switch is in its neutral resting position (section 4.5 of this manual).
3. Make sure the drive and lift arm controls are in neutral positions (controls are spring centered, resting position is neutral).

## 2 SAFETY

---

- Do not attempt to lift heavy parts. Use work aids with sufficient carrying capacity designed for that purpose. Fasten and secure individual parts and large assemblies carefully on lifting equipment to minimize the possibility of objects falling. Use only suitable lifting equipment with no technical defects. Do not work under suspended loads.
- Use only climbing aids and work platforms that meet safety requirements for assembly tasks above body height. Do not use machine parts as climbing aids if they were not designed for that purpose.
- If working at significant height, use a safety harness of the proper style and capacity to prevent falls. Keep all grips, steps, platforms, ladders, etc. free of dirt, snow and ice.



### **2.19 Battery (corrosive)**

- Use caution, wear face shield, safety gloves, and any other appropriate safety equipment when working near or with the battery. The battery contains acid and should be handled with care.
- **DO NOT** smoke or allow open flame or sparks near the battery. Explosion could result.
- When disconnecting the battery, disconnect the **negative** terminal **first**.
- When connecting the battery, connect the **negative** terminal **last**.



### 2.20 Hydraulic Hoses/Lines

- Repairs to hydraulic hoses and hydraulic hose lines are forbidden! These repairs must be performed by trained personnel.
- All hoses, hose lines and screw connections must be checked daily for leaks and externally visible damage! Replace any damaged parts immediately! Oil spraying out can cause injuries and burns.
- Even if they are stored properly and subject to proper loads, hoses and hose lines are subject to natural aging. Their service life is therefore limited.

Improper storage, mechanical damage and impermissible load are the most frequent causes of failure.

The usage period of a hose line should not exceed 6 years, including a storage time of no more than 2 years.

Operation under extreme conditions (examples: frequent exposure to heavy loads, high or low temperatures, extended operating times) will further reduce hose service life.

- Hoses and hose lines must be replaced if any of the following criteria are encountered during inspections:
  - damage to the outer hose up to the insert (for example worn spots, cuts and tears)
  - embrittlement of the outer layer (formation of cracks in the hose material)
  - deformation when under pressure, without pressure or when bending which differ from the original shape of the hose or hose line, for example separation of layers, formation of bubbles or leaks
  - damage resulting from improper installation
  - damage or deformation to the hose fitting that reduces the stability of the fitting or the hose/fitting connection
  - hose coming loose from the fitting
  - corrosion of the fitting that reduces functionality and stability
  - exceeding storage times and usage periods
- When replacing hoses and hose lines, use only original equipment replacement parts. Install hoses and hose lines properly. Do not confuse connections.


This Page Intentionally Left Blank

	Page
3.1 General Structure.....	31
3.2 Views .....	32
3.3 Engine .....	32
3.4 Electrical .....	32
3.5 Undercarriage .....	32
3.6 Transmission .....	33
3.7 Auxiliary Hydraulics.....	33
3.8 Ground Pressure .....	33
3.9 Operating Specifications.....	33
3.10 Dimensions and Weights.....	33
3.11 Service / Refill Capacities.....	34
3.12 Fluid Specifications.....	34

This Page Intentionally Left Blank



#### 3.1 General Structure




#### Key

1. Auxiliary Hydraulic Quick Couplers (see section 4.5)
2. Product PIN Plate (beside operator seat, inside enclosure)
3. Operator Enclosure (R.O.P.S./F.O.P.S. approved)
4. Hydraulic Oil (fill location)
5. Diesel Fuel (fill location) (see section 2.10)
6. Hood (engine cover)
7. Engine
8. Drive Motor and Sprocket
9. Undercarriage
10. Quick Attach
11. Bucket
12. Lift Arm

## 3 TECHNICAL DATA

### 3.2 Views



### 3.3 Engine

Make	Perkins
Type	403J - 17T
Design	Diesel, 3 cylinder, turbo
Displacement	103 in. <sup>3</sup> (1.7L)
Power	25 hp (18.6 kW) @ 2800 RPM
Admissible inclined Positions	25° all directions (engine)
Cooling	Water-antifreeze for all-year operation

### 3.4 Electrical System

Operating Voltage	12 V
Battery	12V 525 CCA
Alternator	12V 65A
Starter	12V
Starting Aid	Glow Plugs, w/manual pre-heating relay
Lighting System	Cab mounted work lights

### 3.5 Undercarriage

Type	Suspended, rubber track w/ screw tension
Travel Speed (max)	5.1 mph (8.21 kph)
Drive Motors	fixed disp. / radial piston motor
Track length, on ground	55 in. (139.7 cm)

### 3.6 Transmission

Make	Rexroth
Type	AA10VG18
Design	Variable displacement / axial piston pump
Displacement	1.098 in. <sup>3</sup> (18.0 cc) / revolution
Relief Pressure	4350 psi (29,990 kPa)

### 3.7 Auxiliary Hydraulics

Make	Rexroth
Design	Gear
Displacement	.873 in. <sup>3</sup> (14.3 cc) / revolution
Relief pressure	3000 psi (20,684 kPa)
Flow	11.3 gpm (42.8 lpm)

### 3.8 Ground pressure

At operating weight	3.1 psi (21.4 kPa)
---------------------	--------------------



### 3.9 Operating Specs.

Tipping load	1900 lb (862 kg)
Operating capacity (50% tip load)	950 lb (431 kg)
Operating capacity (35% tip load)	665 lb (302 kg)

**Note:** The Maximum Gross Vehicle Weight of the RT-25 is not to exceed 4855 lb (2202 kg). This includes an operator, accessories, attachments and material being carried.

### 3.10 Dimensions and Weights

Length w/o bucket	90.5 in. (2299 mm)
Length w/bucket	114 in. (2896 mm)
Width	48 in. (1219 mm)
Height (to top of cab)	72.5 in. (1840 mm)
Ground Clearance	10 in. (254 mm)
Weight (operating)	3755 lb (1703 kg)
Weight (shipping) w/o bucket	3369 lb ( 1528 kg)

### 3 TECHNICAL DATA

---

#### 3.11 Service / Refill Capacities (approximate)

Fuel tank	10 gal (37.9 l)
Hydraulic tank	4.2 gal (15.9 l)
Engine coolant	1.5 gal 5.6 l)
Engine oil including filter	6.3 qts (6 l)

#### 3.12 Fluid Specifications

<u>Specifications</u>	<u>Designation</u>	<u>Specification/standard</u>
Fuel	Diesel Fuel	Ultra Low Sulfur Diesel ASTM S-15
Engine Oil	Engine Oil	SAE 10W-30 (API CH-4)
Engine Coolant	Coolant	Antifreeze/Water (w/SCA additive)
Hydraulic Oil	Hydraulic Oil	Mobil DTE 10 Excel Series 46
Lubricating Points	MP Grease	Multi-purpose lithium grease

---

**Note:** Mobil DTE 10 Excel Series 46 hydraulic oil is recommended for your machine. If not available, use only hydraulic oil that has equivalent specifications.

---


## 4 MACHINE DESCRIPTION / CONTROLS

	Page
4.1 Display Elements.....	37
4.2 Symbols .....	38
4.3 Controls .....	40
4.4 Throttle .....	40
4.5 Auxiliary Hydraulics.....	41
4.6 Electric Attachment Control .....	42
4.7 Emergency Exits .....	42
4.8 Attachment Compatibility.....	43

This Page Intentionally Left Blank

## 4 MACHINE DESCRIPTION / CONTROLS

### 4.1 Display Elements




Learn the location and function of these items prior to operation.

#### Switches

- 1 - Lights, front and rear
- 2 - Heater Fan (optional)
- 3 - Front wiper (optional)
- 4 - Beacon (optional)
- 8 - Ignition, glow plug (pre-heat)
- 9 - Auxiliary Hydraulics

#### Instruments & Equipment

- 5 - Fuel Level Gauge
- 6 - Warning Indicators (4-in-one)
- 7 - Hour Meter
- 10 - Glow Plug Operation Light
- 11 - Rearview Mirrors
- 12 - Dome Light
- 13 - Oil Pressure Warning Light
- 14 - Battery Voltage Warning Light
- 15 - Hydraulic Oil Temp. Warning Light
- 16 - Engine Temp. Warning Light



#### NOTICE

Should the engine coolant temperature, oil pressure or hydraulic oil temperature warning lights illuminate during normal operation, shut the machine down immediately (in a safe location). Diagnose the problem and make needed repairs before continuing to operate.










If the battery voltage light (14) illuminates, drive the machine to a suitable location and shut the engine off. Diagnose the problem and make any necessary repairs before resuming operation.

The glow plug operation light (10) will illuminate only when the key switch is turned to engine pre-heat, showing normal operation.

## 4 MACHINE DESCRIPTION / CONTROLS

---



### 4.2 Symbols

Symbol	Description
	Engine Pre-heat
	Battery
	Engine Speed: Fast
	Engine Speed: Slow
	Windshield Wiper
	Beacon Light
	Oil Pressure
	Engine Coolant Temperature
	Hydraulic Oil Temperature



## 4 MACHINE DESCRIPTION / CONTROLS

---

Symbol	Description
 A symbol for work lights, consisting of a semi-circle on the right and three horizontal lines of varying lengths extending to the left from the semi-circle's edge.	Work Lights
 A symbol for a fan, consisting of a central circle with four curved blades extending outwards.	Fan


## 4 MACHINE DESCRIPTION / CONTROLS

### 4.3 Controls

The RT-25 has two hydraulic pilot joystick controls. The joysticks are used to control machine speed and direction as well as lift arm and bucket functions.

#### 4.3.1 Lift Arm Control

The lift arm joystick is used to control the lift arms, bucket, and to engage the float function. The illustration shows the relationship between joystick movement and resulting lift arm action.



**Note:** To activate the float function, move the joystick fully forward in a quick motion. The joystick will then be held in detent by the magnet attached to the joystick base. Pull back quickly to disengage the float function.


#### 4.3.2 Drive Control

The drive joystick controls the direction and speed of the machine. The illustration above shows the relationship between joystick movement and resulting machine motion.

### 4.4 Throttle

The throttle (hand lever) is located to the right of the operator's right leg when seated in the machine. The throttle controls engine rpm.

- Move the lever forward to increase engine RPM.
- Move the lever rearward to decrease engine RPM.
- Select a lower rpm for work that requires delicate operation of the machine.
- Select a higher rpm for faster travel speed or when more power or flow is required for a task.




### 4.5 Auxiliary Hydraulics

The RT-25 models come equipped with an auxiliary hydraulic system designed to power compatible hydraulic attachments.

To operate, connect the attachment to the quick couplers (fig. 4.5-1).

#### To connect couplers:

1. Clean couplers thoroughly (both ends).
2. Push the male and female coupler ends together, then turn coupler collar 1/4 turn to lock.



The auxiliary hydraulics can be engaged intermittently or continuously depending on the requirements of the attachment being utilized.

To engage the hydraulic flow intermittently, activate the toggle-type switch on the top of the right joystick (fig. 4.5-2).

To engage the hydraulic flow continuously, activate the 3-position switch on the dash panel, labeled 2 in figure 4.5-3.

---

**Note:** Moving either switch from one position to the other has the effect of reversing flow through the auxiliary hydraulic circuit.

---

---

**Note:** The continuous flow switch must be in its neutral position in order to start the engine.


---

---

**Note:** The continuous flow auxiliary switch has a small orange locking device that must be disengaged before the switch will activate.

---



## 4 MACHINE DESCRIPTION / CONTROLS



### 4.6 Electric Attachment Control (optional)

Attachments for the RT-25 are controlled by pressing various buttons on the joysticks or switches in the cab. Most attachments are controlled hydraulically, but some require both hydraulic and electrical inputs. The upper 4 buttons on the left joystick (4.6-1) can send up to 20 amps (combined) of electrical current to pins B, C, D, G of the receptacle on the lift arms (4.6-1). Attachments requiring electrical inputs must have a matching receptacle.

**Note:** The electrical receptacle may not be compatible with other brands. Use only compatible attachments for proper function.



### 4.7 Emergency Exits

Familiarize yourself with the emergency exits and associated features located throughout the cab enclosure prior to operation. These features allow an operator to escape from the cab in an emergency.

**Operator Escape (Door Exit):** Firmly grasp the triangular tag attached to the window molding on the front door. Pull on the tag forcefully to remove the window molding, then push or kick the window out to escape (fig. 4.7-1).

**Operator Escape (Rear Hatch Exit):**

1. Firmly grasp the levers on each side of the rear window hatch assembly and pivot them inward and downward, then open the hatch to escape (fig. 4.7-2).
2. If the rear hatch is locked, the right lever (when viewed from inside) will not move. You must firmly grasp the red knob on the right side of the rear window (secures the lever to the hatch) and rotate it counterclockwise to remove it. Push the hatch outward forcefully at the bottom to open and escape (fig. 4.7-3).

---

## 4 MACHINE DESCRIPTION / CONTROLS

### 4.8 Attachment Compatibility

There are many things to consider when determining if an attachment is compatible with your RT-25 Compact Track Loader (CTL). The following criteria must be met in order for an attachment to be considered compatible.

**A compatible attachment must:**

- Be designed for use with the RT-25 CTL quick attach system. It must mate and attach securely to the machine using the supplied quick attach and locking pins (see sections 5.9-5.10).
- Not cause the machine to operate in excess of the GVW rating (see chapter 3) at any time during use. This includes any loads that may be carried or forces that may be applied to the attachment or by the attachment.
- Not cause the machine to operate in excess of the rated operating capacity at any time during use. This includes any loads that may be carried or forces that may be applied to the attachment or by the attachment (see chapter 3).
- Have a matching electrical attachment receptacle (if electrical actuation is required) and not require electrical input in excess of the 20 amp max supplied by the machine (section 4.6).
- Have matching auxiliary hydraulic quick couplers and components that are designed to operate within the range of pressures and flows supplied by the CTL auxiliary hydraulic system (see chapter 3).
- Not detrimentally impact machine stability during operation.
- Be designed for use with a machine of this size, weight and capability and in line with the intended use of the machine (see introduction) taking into consideration: Operating Capacity, ROPS/FOPS rating, Engine HP, Electrical and or hydraulic input requirements.
- Be used in conjunction with any necessary auxiliary equipment or PPE required to maintain the safety of the operator and any bystanders during use (example: reinforced polycarbonate door and full cab package for use when brush cutting).

---

**Note:** The operator must follow the operating instructions (manuals) for any externally supplied components or attachments.

---

If the attachment you intend to use does not meet the above criteria, it is not considered a “compatible” attachment and should not be used.

This Page Intentionally Left Blank

	Page
5.1 General Information.....	47
5.2 Pre-Operation Safety Checklist.....	47
5.3 Starting Procedure .....	48
5.4 Surface Preservation.....	49
5.5 Filling the Bucket .....	49
5.6 Grading.....	50
5.7 Leveling .....	50
5.8 Loading.....	51
5.9 Fastening Attachments.....	51
5.10 Unfastening Attachments .....	52
5.11 Operation on Inclines .....	53
5.12 Shut-Down Procedure .....	53
5.13 Lift Arm Brace .....	54

This Page Intentionally Left Blank



### 5.1 General Information

Safe operation is the responsibility of the operator (**see chapter 2, Safety**). Be aware of your surroundings at all times. Keep a safe distance from bystanders at all times during operation. Always look in the direction of travel.



### 5.2 Pre-Operation Safety Checklist

Before operating the machine, perform a pre-operation safety check. Inspect the machine for any items that may affect safe operation.

#### Check to make sure:

1. Engine compartment, chassis and coolers are clean and free of debris.
2. Windows and lights are clear, clean, unobstructed. Visibility is not impaired.
3. Tracks are in good condition and are properly tensioned.
4. Fluids are filled to proper levels.
5. Fan / accessory belt(s) are in good condition and properly tensioned.
6. Hydraulic hoses and fittings are in good condition. (no visible signs of wear)



Never use bare hands to check for leaks! Pressurized oil can penetrate skin and cause gangrene. Seek medical attention immediately from a physician familiar with this type of injury!

7. Battery cables are in good condition and properly fastened.
8. Joysticks, auxiliary hydraulic switch are in neutral position.
9. The R.O.P.S./F.O.P.S. approved operator enclosure is not damaged or distorted structurally in any way and is securely fastened to the chassis.
10. The seat belt and lap bar restraint are in good working order.
11. All safety signs are in place and legible on the machine.
12. All control devices are present, in good operating condition, and are not damaged in any way.
13. The rear view mirror(s) (if equipped) is adjusted for proper viewing.
14. Ensure all guards, shields and access panels are in place and secure.
15. The backup alarm is audible when the drive control is moved rearward.
16. You have read and understood the information in this manual in its entirety.

**Note:** If any of the items listed above are not as described, they must be corrected / repaired prior to operation.

---

17. The safety circuit is functioning properly by performing the following:
  - A. Start the engine according to section 5.3.
  - B. Raise the lap bar, then attempt to curl the bucket.
  - C. Lower the lap bar.
  - D. Raise yourself off of the seat to remove pressure from the operator presence safety switch located in the seat, then attempt to curl the bucket.

**Note:** If the bucket moves during either of these tests, the safety circuit is not functioning properly. It must be repaired prior to operation.

---

## 5 OPERATION



### 5.3 Starting Procedure

Before starting the engine, perform the pre-operation safety checklist. Once complete, you may proceed by following this procedure:

1. Enter machine with lift arms all the way down. Maintain three points of contact with the machine (fig. 5.3-1).
2. Sit down into the operator's seat, fasten seat belt, then lower lap bar into position.



Personal Protective Equipment should be worn during operation in accordance with section 2.5 of this manual.

3. Starting with the throttle in the SLOW (turtle icon) position, push the throttle 1/3 the way open (toward the rabbit icon).
4. Turn the ignition key to the left for 6 seconds to "pre-heat" the engine. While pre-heating, the glow plug operation light will illuminate.
5. Turn the ignition key to the right to start the engine.
6. With the exhaust adequately vented, bring the engine and hydraulic oil up to operating temperature. Low oil temperatures can cause the control system to respond sluggishly.
7. Set the throttle to desired rpm for operation.


**Note:** The parking brake is automatically engaged when the machine is turned off.



Entering or exiting the vehicle under raised lift arms could result in injury or death. Never allow anyone beneath raised, unsecured lift arms (fig. 5.3-2).

### 5.4 Surface Preservation


RT-25 Compact Track Loaders are designed to produce minimal ground disturbance while operating on finished surfaces like turf, however, care should be taken while operating on these surfaces to prevent blemishes from occurring.



Turning poses the greatest risk of surface disturbance during operation. Moving in a straight line across turf will cause little or no disturbance, whereas tight cornering will most likely cause blemishes.

While working on turf, make gradual turns. (see item A) If space is limited, turn gradually by moving back and forth until facing the desired direction. (see item B)

### 5.5 Filling The Bucket




#### Steps: (see illustration, section 5.1)

1. Lower the lift arms until they rest on the frame.
2. Tilt the bucket slowly forward until the cutting edge engages the ground.
3. Drive the machine forward until the bucket is full of material.
4. Curl the bucket and raise the lift arms simultaneously to break the load free from the pile.
5. Maneuver the machine clear of the pile and then lower the lift arms, keeping the bucket curled upward, to approximately 10-12 inches (25-30 cm) above the ground for transporting.

## 5 OPERATION

### 5.6 Grading




#### Steps: (see illustration, section 5.1)

1. Lower the lift arms until they rest on the frame.
2. Tilt the bucket slowly forward until the cutting edge engages the ground.
3. Drive the machine forward making slight bucket angle adjustments to vary cut depth as necessary.
4. When full, curl the bucket and raise the lift arms simultaneously. Once clear, lower them to approximately 10-12 inches (25-30 cm) above the ground for transporting.

#### NOTICE

Do not push or pull dirt as done in digging, grading, or leveling operations with the bucket tilted fully forward into the “Dump” position. This will stress the bucket cylinders and may damage them.


### 5.7 Leveling



#### Steps: (see illustration, section 5.1)

1. Moving forward, raise the lift arms as you tilt the bucket slowly forward to evenly spread the material out over the ground.
2. Once the load is released, tilt the bucket forward to an angle 45° or less to the ground.
3. Lower the lift arms until the cutting edge rests on the ground.
4. Engage the float function and back the machine over the material varying bucket angle slightly as necessary to maintain grade.

## 5.8 Loading




### Steps: (see illustration, section 5.1)

1. Raise the lift arms upward, carefully maintaining the bucket angle, until the bottom of the bucket clears the side of the truck bed or trailer.
2. Once clear, drive the machine forward until the pivot point of the bucket clears the bed side.
3. Tilt the bucket forward until all of the material has been released into the bed.

**Note:** It may be necessary to quickly tilt and curl the bucket while releasing material into the truck bed to evenly distribute the material within the bed.

## 5.9 Fastening Attachments (see also section 5.1)




1. Make sure the locking levers on the quick attach mechanism are in their respective unlocked positions. (fig. 5.10-1)
2. Drive the machine to the attachment and hook the top edge of the quick attach under the upper lip of the attachment.
3. Curl the quick attach slowly upward by moving the lift arm control joystick to the left until the attachment is properly mated with the quick attach mechanism. (Curl enough to lift the attachment off of the ground.)
4. Once the attachment is properly mated, move the two locking levers inward and downward to lock the attachment in place.




**Note:** When fastening an attachment, always visually verify that the attachment is locked in place prior to operation. (fig. 5.10-2 & 5.10-3)

## 5 OPERATION

### 5.10 Unfastening Attachments (see also section 5.1)



1. Lower the lift arms so that the attachment is just barely off the ground.
2. Pull the locking levers on the quick attach mechanism upwards and toward the outside of the machine to unlock the attachment.
3. Lay the attachment gently onto the ground by moving the lift arm control joystick slowly to the right.
4. Once the attachment is in contact with the ground, move the lift arm control joystick gently to the right until the quick-attach is clear of the attachment.
5. Back the machine away from the attachment.



### 5.11 Operation on Inclines

By design, Compact Track Loaders are very stable on inclines. Machine weight is distributed evenly throughout the chassis and the suspended undercarriage track system provides excellent traction and floatation on nearly all surfaces.



Even with these capabilities, extreme caution should always be exercised while operating the machine on an incline. Avoid operation on steep inclines. Do not make sudden changes in direction, move slowly, and always carry loads low to maximize machine stability.

### 5.12 Shut Down Procedure

1. Stop and lower any work attachments that may be coupled to the machine.
2. Stop the machine in a safe location (on firm and level ground) where it is protected from the elements and vandals.
3. Lower the lift arms until they rest on the frame stops.
4. Reduce engine RPM to a low idle.
5. Turn the ignition key counterclockwise to stop the engine, remove key.
6. Remove the seat belt and raise the lap bar.
7. Open the door (if equipped) and exit the machine using 3 points of contact as described in the starting procedure (section 5.3).

## 5 OPERATION

### 5.13 Lift Arm Brace

When the lift arms must be left in the raised position, the lift arm brace must be engaged.

To install:

1. Lower the lift arms, remove any attachments and park the machine on firm and level ground.
2. Have an assistant withdraw the retaining pins from the lift arm brace on the fender, remove the brace, then stand clear.
3. Raise the lift arms to the upper limit to allow for brace installation.
4. Have the assistant place the lift arm brace onto the top side of the cylinder ram and install the retaining pins to secure it there, then stand clear (fig. 5.13-2).
5. Slowly lower the lift arms until they come to rest on the brace.

To remove:

1. Raise the lift arms until they are clear of the brace.
2. Have an assistant withdraw the retaining pins and remove the brace from the cylinder, then stand clear.
3. Lower the lift arms to the lower stop.
4. Position the lift arm brace over the fender brackets as found and install the retaining pins to secure it there.



Do not go beneath unsecured lift arms. Always install the lift arm brace prior to going beneath the lift arms while raised.




**6 TRANSPORTATION**

---


	Page
6.1 Transporting.....	57
6.2 Tie Down Points.....	58
6.3 Towing / Retrieving .....	58
6.4 Loading / Unloading Procedure .....	60

This Page Intentionally Left Blank



### 6.1 Transporting

At times, you will most likely need to transport the machine to distant locations with a transport vehicle. To do this safely, there are some precautions that must be observed.



When transporting:

1. Always make sure the transport vehicle (trailer or truck) being used to haul the machine is capable of bearing the weight and size of the machine over the distance and terrain that will be covered.
2. Secure the machine to the transport vehicle bed with heavy chains rated for use with a machine of this nature (size and weight).
3. Attach the chains to the machine at four points (D-rings), one on each corner of the machine and secure to suitable locations on the transport vehicle (Items A and B, fig. 6.1-1 and 6.1-2). Tighten as needed to eliminate possible load shift during transport.

---

**Note:** Close and latch doors and windows, secure any loose items prior to transporting.

---

## 6 TRANSPORTATION

---

### 6.2 Tie Down Points

This section covers intended/proper use of tie down points on the RT-25.

**Tie Down Points:** The RT-25 has 4 tie down points (fig. 6.1-1 and 6.1-2, items A and B). Tie down points “A” are to be used **ONLY** for securing the machine to a trailer during transport.

Tie down points “A” are **NOT** to be used as anchor points for lifting, moving or retrieving the machine in any way, nor are they to be used to lift, move or extract objects of any kind, in any way.

---

**Note:** Points B (fig. 6.1-2) serve multiple purposes (see also sections 6.1 and 6.3).

---

Any use of the machine tie down points varying from that described in this manual shall be regarded as unintended or improper use. The supplier cannot be held responsible for any damage resulting from improper use. This risk is borne solely by the user.

#### 6.2.1 Tie Down Guidelines

Below are guidelines that must be followed when tying the machine down for transport. Chains must not contact the bucket or other attachment while in use for tie down purposes.

##### Front Tie Down Points (see figure 6.2-1)

When securing the machine at the front using tie down points “A” (fig. 6.1-1), chains must extend forward a minimum of 9” from points “A” on either side of the machine with a minimum chain length of 43.8”. The chains may only extend forward up to 16” from points “A” (max. chain length of 45.8”).

##### Rear Tie Down Points (see figure 6.2-1)

When securing the machine at the rear using tie down points “B” (fig. 6.1-2), chains must extend rearward a minimum of 33” from points “B” on either side of the machine with a minimum chain length of 70.7” (crossed) or 51.9” (not crossed).

### 6.3 Towing / Retrieving the RT-25

In the event that the RT-25 needs to be towed or retrieved, it will not roll freely. You must drag it to safety. Use only chains that are rated for pulling a machine of this size and weight. Attach these chains to **BOTH** multi purpose anchor points (items B, fig. 6.1-2) at the rear of the machine.

---

**Note:** When connected, chains should be attached so that they extend straight backward from points “B” (fig. 6.1-2) and must remain within 20° of the original position (in all directions) throughout the retrieval process (fig. 6.3-1).


**Machine weight (including accessories, attachments or material being carried) MUST NOT exceed 3950 lb (1792 kg) during retrieval.**

---

Once secure, pull the machine from the rear **ONLY**. If possible, drag the machine onto a trailer, then secure and transport.

6.2-1

**Note:** If an attachment causes machine weight to exceed 3950 lb (1792 kg), the attachment must also be secured.





FRONT

Bucket and lift arm excluded from illustration for clarity.

TOP VIEW

SIDE VIEW

REAR



6.3-1

## 6 TRANSPORTATION

---

### 6.4 Transport Loading / Unloading procedure

1. If loading onto a trailer, the trailer must be securely attached to the towing vehicle. The towing vehicle must have the wheels blocked or parking brake engaged.
2. Load the machine only on firm and level ground.
3. Before driving onto the ramps, clean them and the machine tracks of any materials that may cause slippage (snow, ice, water, mud, sludge, oil, etc.).
4. Properly align the machine with the loading ramp.
5. Have a guide give the machine operator any necessary signs to maximize safety during loading.
6. Back the machine carefully up the ramps and onto the transport vehicle.

---

**Note:** The heaviest end of the machine should remain uphill when operating on an incline. Always back the machine onto the transport vehicle unless fitted with a heavy attachment or loaded bucket.

---

7. Have a guide instruct you as to where and when to stop and park the machine. Lower the lift arms and turn off the engine.
8. Before securing the machine, relieve all residual pressure by making sure the operating levers and the auxiliary hydraulic switch are in their neutral positions. Remove the ignition key.
9. Secure the door, windows and hood on the machine.
10. Secure the machine and any other items to the transport vehicle with chains or ropes of the proper capacity.
11. Before departure, investigate the route to be taken, especially in regard to limits for width, height and weight.
12. Pay close attention when driving under electrical lines, bridges, or through tunnels.



Electrocution hazard exists if electrical lines are contacted! Stay clear of electrical lines!

13. To unload, reverse steps 1-10 of this procedure. Use the same caution when unloading as for loading. Remove all cables or chains. Start the engine as described in the operating instructions. Carefully drive down the ramp from the transport vehicle using a guide if necessary to direct movement.

	Page
7.1 General .....	63
7.2 Care and Cleaning .....	63
7.3 Maintenance Intervals.....	64
7.4 Lubrication Points.....	65
7.5 Engine Oil Check.....	66
7.6 Engine Oil Change.....	67
7.7 Hydraulic Oil Change.....	68
7.8 Hydraulic Filter Change .....	69
7.9 Fan / Accessory Belt .....	69
7.10 Fuel Filter Change .....	70
7.11 General Undercarriage .....	71
7.12 Track Tension Check .....	71
7.13 Track Tension Adjustment .....	72
7.14 Drive Sprocket Rollers.....	73
7.15 Air Cleaner Inspection .....	74
7.16 Air Cleaner Service .....	75
7.17 Radiator Oil Cooler Cleaning.....	76
7.18 Engine Coolant Change .....	76
7.19 Chassis Cleaning .....	77
7.20 Electrical System.....	78
7.21 Storage .....	79
7.22 Lifting (Jacking) Procedure.....	81

This Page Intentionally Left Blank



### 7.1 General

The operating condition and life expectancy of a machine is largely influenced by care and maintenance. For this reason, it is in every machine owner's interest to perform the specified maintenance work and comply with the service intervals.

This chapter describes periodic maintenance, inspection and lubricating tasks. The maintenance interval charts list all work to be performed on the machine at regular intervals.

---

**Note:** Always use genuine original equipment replacement parts when performing maintenance or service to maintain the highest possible level of quality.

---

The supplemental engine operation and maintenance manual (access information provided on the back of the cover page in this manual) contains information specific to the proper operation, inspection and maintenance of the engine and its internal components. This manual must be read, understood and followed in order to properly maintain the engine and comply with warranty requirements.



The operator must have sufficient knowledge to inspect and maintain the machine. The operator should follow the procedures in this manual and take any necessary precautions to ensure his/her safety. Wear appropriate personal protection equipment for all tasks.

### 7.2 Care and cleaning

Cleaning the machine

- Do not use aggressive detergents to clean the machine. We recommend using commercially available cleaning agents for passenger cars.
- Linings (insulating materials, etc.) should not be exposed directly to water, or high-pressure jets.
- When cleaning with water jets, take care not to direct the jet into exhaust and air filter openings and do not expose sensitive engine parts, such as alternator, wiring, oil pressure switches, etc. directly to the jet.
- Do not clean the machine with hot water in excess of 140° F or steam as it can accelerate the formation of corrosion on zinc plated components.
- Pay particular attention to the radiator / oil cooler, engine compartment, and chassis area when cleaning. Remove any visible debris from these areas prior to cleaning.
- After wet cleaning lubricate the machine as specified in section 7.4 prior to operation.
- Inspect the machine after cleaning for the presence and condition of safety signs. If any are missing or damaged, contact your dealer immediately to obtain a replacement.

## 7 MAINTENANCE

---

### 7.3 Maintenance Intervals

#### 7.3-1 Daily Maintenance Tasks


<b>Daily</b>		<b>Page</b>
1	Check hydraulic oil level (figure 7.7-3, p-68)	68
2	Check engine oil level	66
3	Check fuel level (gauge on instrument panel)	37
4	Check track tension / condition	71
5	Check for proper control operation	40
6	Check safety circuit for proper operation	47
7	Check for proper switch and lighting operation	37
8	Inspect air cleaner dust load indicator	74
9	General visual check for cracks, damage, completeness	20,47
10	Check for leaks in hoses, tubes, valves, pumps, cylinders, etc.	18,27,47
11	Lubricate all grease points	65
12	Inspect / clean the radiator/cooler and engine compartment	76-77

#### 7.3-2 50-1000 hour Tasks

<b>Every 50 operating hours</b>		<b>Page</b>
1	Inspect drive sprocket rollers (replace as needed)	73
2	Check track tension (adjust as needed)	71,72
<b>Every 250 operating hours</b>		<b>Page</b>
1	Replace hydraulic filter	69
2	Check accessory belt tension / condition	69
<b>Every 500 operating hours</b>		<b>Page</b>
1	Replace engine oil & filter	67
2	Replace fuel filter elements	70
<b>Every 1000 operating hours</b>		<b>Page</b>
1	Replace hydraulic oil	68
2	Replace engine coolant (use SCA additive, see engine manual)	76

### 7.4 Lubrication Points

The illustration below shows the location of grease points found on the left side of the machine. Identical points also exist on the opposite side of the machine. Lubricate all points daily, prior to operation.




- A. Lower Bucket Cylinder Pivot**
- B. Upper Bucket Cylinder Pivot**
- C. Front Lift Cylinder Pivot**
- D. Door Hinges (if equipped)**
- E. Lift Arm Pivot**
- F. Rear Lift Cylinder Pivot**
- G. Rear Axle Pivot**
- H. Front Axle Pivot**
- I. Quick Attach Pivot**


## 7 MAINTENANCE

### 7.5 Engine Oil Check


1. Shut the machine down according to the procedure in section 5.12.
2. Open the hood to gain access to the engine compartment.
3. Locate and remove the engine oil dipstick (1) from its tube. (fig. 7.5-1)



4. Wipe the dipstick with a clean shop cloth and reinsert it into the tube until it comes to rest in its seated position.
5. Remove the dipstick once again and inspect the end for oil on the level indicator.



6. Oil should be present on the dipstick up to, but not over the upper (full) level indicator notch. If the level is correct, reinstall the dipstick and then close and latch the hood to complete the procedure. (fig. 7.5-2)
7. If the level is low, add the proper grade and viscosity engine oil and re-check as necessary until the proper level has been achieved. Then re-install the dipstick and filler cap and close and latch the hood to complete the procedure.



### 7.6 Engine Oil Change

Regular oil changes are necessary to maintain a strong running engine. A normal oil change interval of 500 hours or every one year is recommended. Allow the machine to cool prior to service. Wear safety glasses, safety gloves and any other items necessary to ensure your safety while performing maintenance or service.

To change engine oil:



1. Shut the machine down according to the procedure in section 5.12 and allow the machine to cool prior to performing this procedure.
2. Remove the belly pan beneath the engine to access the drain.
3. Remove the oil drain plug (1) from the pan.
4. Drain the oil into a suitable catch container.
5. Remove engine oil filter (2). Upon removal, make sure the old filter gasket (3) is still present on the filter. If not, remove it from the filter port on the engine prior to installing the new filter to prevent leaks.
6. Apply fresh oil to the new filter gasket surface and install the new filter.
7. Tighten the new oil filter to specifications on filter label or box.
8. Reinstall the drain plug removed in step 3 and tighten.
9. Refill the engine to capacity at the location labeled 4 above with oil as specified in the chapter 3, Technical Data.
10. Reinstall the belly pan as found upon removal, and dispose of the used oil and filter according to mandates.




Oil and machine components can be HOT! Allow the machine to cool thoroughly prior to performing maintenance or service to avoid the possibility of burns.

## 7 MAINTENANCE

### 7.7 Hydraulic Oil Change



The hydraulic oil should be changed every 1000 service hours. Before beginning the procedure, make sure the machine is in a clean working environment. Take any necessary measures to prevent dirt or debris from entering the hydraulic system.



To change hydraulic oil and filter:

1. Shut the machine down according to the procedure in section 5.12.
2. Allow the machine to cool, then release any residual pressure in the hydraulic system by following the procedure in section 2.18 of this manual.
3. Remove the belly pan beneath the center of the machine, then locate and disconnect the designated hose from its fitting to drain (item 1) (fig. 7.7-1)
4. Drain the used oil into a suitable catch container.
5. Dispose of the oil according to mandates.
6. Reconnect the drain hose removed in step 3 and tighten.
7. Reinstall the belly pan removed in step 3.
8. Refill the hydraulic reservoir (item 3) with Mobil DTE 10 Excel Series 46 Hydraulic Oil, or equivalent. (fig. 7.7-2)

**Note:** Observe the hydraulic oil level sight gauge (item 4) located on the back of the hydraulic reservoir to ensure that the level is correct (fig. 7.7-3).

9. Once full, start the engine according to the proper starting procedure and operate all hydraulic circuits to work any trapped air out of the system. Then, check the oil level. If low, add oil as necessary until full.

### 7.8 Hydraulic Filter Change

The hydraulic filter should be changed every 250 hours. Hydrostatic components require extremely clean oil in order to have a long service life. Use caution when changing the hydraulic filter. Before beginning the procedure, make sure the machine is in a clean working environment. Take any necessary measures to prevent dirt or debris from entering the hydraulic system.

To change the hydraulic filter:

1. Shut the machine down according to the procedure in section 5.12.
2. Allow the machine to cool, then release any residual pressure in the hydraulic system by following the procedure in section 2.18 of this manual.
3. Locate the hydraulic filter behind the operator enclosure, under the left rubber plug (item 2, fig. 7.7-2).
4. Clean around the filter head, then remove the three bolts securing the cover and remove it.
5. Remove the old filter from the housing and replace it with a new element. Dispose of the used filter according to mandates.
6. Reinstall the cover and rubber plug as found upon disassembly.


**Note:** Should a hydraulic hose or fitting need to be removed for maintenance or service, always inspect for damage prior to re-installation. If none is found it may be reused; if damaged, replace the part.

### 7.9 Fan / Accessory Belt

The engine uses a belt to drive accessories. The accessory belt on the RT-25 should be visually inspected every 250 hours for tension, condition and presence prior to operation.

To check / tension the belts:

1. Shut the machine down according to the procedure in section 5.12, allow the machine to cool.
2. Open the hood at the rear of the machine.
3. Visually inspect the belt to make sure it is present, tight around the pulleys and in good condition.




## 7 MAINTENANCE

### 7.10 Fuel Filter Change

The fuel filter(s) should be changed every 500 service hours, or as needed. A plugged fuel filter can cause loss of engine power, rough running, or no start.

To change the primary filter:


1. Shut the machine down according to the procedure in section 5.12, then open the hood at the rear of the machine to access the fuel filter.
2. Clean the outside of the filter (1) thoroughly (fig. 7.10-1).
3. Remove bolt (2) on the top of the filter assembly, then remove filter. (fig. 7.10-1)
4. Reverse step 3 to install the new fuel filter into the machine.



**Note:** Drain fluids into a suitable catch container. Dispose according to mandates.

To change the pre-filter:

1. Shut the machine down according to the procedure in section 5.12, then open the hood at the rear of the machine to access the fuel pre-filter.
2. Clean the outside of the filter (item 27) thoroughly (fig. 7.10-2).
3. Remove the fastener securing the clamp (28) holding the pre-filter (27) to the reservoir. Remove clamps (23) from the fuel hoses leading to and from the filter (27). Disconnect the hoses from the filter (fig. 7.10-2).
4. Remove the filter from the machine, then reverse step 3 to reinstall a new filter in its place.



**Note:** Drain fluids into a suitable catch container. Dispose according to mandates.



### 7.11 General Undercarriage Information

The undercarriage assemblies typically operate in harsh working conditions. They work in mud, gravel, debris and various other abrasive materials during operation. A daily inspection of the undercarriage assemblies and cleaning if necessary is recommended.

Materials that are particularly sticky or abrasive like clay, mud, or gravel should be cleaned from the undercarriages often to minimize component wear. A pressure washer works well for cleaning materials from the undercarriages. At times when a pressure washer is not available, use a bar, shovel or similar device to carefully remove foreign materials.

When cleaning, pay particular attention to the drive motors/sprockets and the front and rear wheels where debris is likely to accumulate. If working in scrap or debris, inspect the undercarriages more often and remove foreign objects that may wrap around or lodge themselves between components causing premature wear and damage.

Operation on sand, turf, or other finished surfaces may require less frequent cleaning, but daily inspection is still advised.


### 7.12 Track Tension Check

Proper track tension is important for optimum performance and maximum track life. Operating with tracks that are too loose can cause them to misfeed, possibly causing damage. During the first 50 hours of operation, the tracks will "break-in", and may require adjustment.

To check for proper track adjustment:



1. Drive the machine forward 5 ft. (1.5 m) to remove slack from the lower and rear portions of the track. Stop the engine and remove the key from the ignition.
2. Lay a straight edge along the top of the track, across the sprocket and the front idler wheel (fig. 7.12-1).
3. Using a rope or wire, put 90 lb (41 kg) of down force on the track at the mid point between the sprocket and front idler wheel.
4. Using a ruler or tape, measure the distance between the straight edge and track (fig. 7.12-2). The track should not deflect more than .75 in. (1.9 cm) between the top of the track and the straight edge.
5. If the track does deflect more than 3/4 in. (1.9 cm), tighten the track until within specification.

## 7 MAINTENANCE



### 7.13 Track Tension Adjust

1. Shut the machine down according to the procedure in section 5.12, then locate the jam nut on the track tension device and clean the threads thoroughly before proceeding. (fig. 7.13-1).
2. Using a wrench, loosen the jam nut (A) on the track tension device.
3. Once the jam nut is loose, turn the lower nut (B) to increase tension until within specification (figure 7.13-2).
4. Turn the lower nut the opposite direction to loosen the track.
5. Once proper tension is achieved, retighten the jam nut (A) on the tensioner.




---


**Note:** If the track tensioner is stiff, it may be helpful to apply a penetrating lubricant onto the threads prior to adjusting tension.

---

## 7.14 Drive Sprocket Rollers



Compact Track Loaders use rollers on each drive tooth of the drive sprockets. These rollers help minimize friction between lugs on the track and the sprocket. Sprocket rollers should be treated as wear items that are inspected regularly and replaced as needed.



The rollers (1) rotate on steel pins (2), limiting wear to the inside of the rollers. As they wear, the rollers become thinner, but will continue to function and perform as long as they are rotating.

Visually inspect rollers every 50 hours and replace any that show signs of cracking or wear-through.


Drive sprocket removal and roller / pin replacement should be performed by your local RT-25 dealer.

## 7 MAINTENANCE

---

### 7.15 Air Cleaner Inspection

A properly functioning air cleaner is necessary to ensure performance and to prolong engine life. **Inspect the dust load indicator daily** to determine if air cleaner service is required.



To inspect:



1. Shut the machine down according to the procedure in section 5.12,
2. Open the hood at the rear of the machine to access the air cleaner housing and dust load indicator.
3. Inspect the dust load indicator for the color red in the clear viewing window.
4. If red is not present upon inspection, reverse step 2 of this procedure to return the machine to operating condition.
5. If red is present in the clear indicator viewing window, the air cleaner must be serviced (section 7.16).

---

**Note:** If the air cleaner does not require service, continue daily dust load indicator inspections and replace elements as needed following the procedure in section 7.16.


---

## 7.16 Air Cleaner Service



To service the air cleaner:

1. Shut the machine down as described in section 5.12, then open the hood to access the air cleaner assembly.
2. Release the latches on either side of the air cleaner housing (items 1, fig. 7.16-1), then remove the cover to expose the primary filter for service.
3. Immediately vacuum the inside of the canister to remove loose dirt.
4. Once any dirt particles have been removed, slowly remove the primary element (item 2 fig. 7.16-2) taking care not to disturb dirt that may be caked around the filter seal. Again vacuum the canister.
5. Remove the secondary element ( item 3, fig. 7.16-3 ) at this time, taking care not to disturb dirt that may be caked around the filter seal. Again vacuum the canister.
6. Wipe the seal areas with a clean damp cloth to remove any remaining dirt.
7. Reverse steps 1, 2, 4 and 5 to install new filter elements prior to resuming operation.

**NOTICE**

Do not clean the filter elements. Instead, replace the filter elements when soiled or damaged to comply with engine warranty requirements and to prolong engine life.

## 7 MAINTENANCE

### 7.17 Radiator / Oil Cooler Cleaning Procedure

The radiator and oil cooler must be clean to ensure proper operation. Engine and hydraulic system overheating, damage and even failure can result if the radiator/oil cooler is not kept clean. A pressure washer or compressed air nozzle work well to blow debris clear of the fins in the oil cooler and radiator.



To clean radiator / oil cooler:

1. Shut the machine down according to the procedure in section 5.12 and allow the machine to cool prior to performing this cleaning procedure.
2. Thoroughly clean radiator / oil cooler with a pressure washer or compressed air. Wear any appropriate safety clothing. Direct spray forward through the cooler as shown. (fig. 7.17-1)

**Note:** If hydraulic oil or engine coolant temperature lights illuminate during operation, clean coolers more often.

### NOTICE


Make sure water nozzle is at least 12 in. (30.5 cm), for air 8 in. (20.3 cm) from the cooler and that the spray is directed straight through the cooler or the cooling fins may be damaged (bent over) which will decrease cooling performance.



In dusty applications check and clean the coolers and chassis often to avoid overheating and prevent fires.

### 7.18 Engine Coolant Change Procedure

1. Shut the machine down according to the procedure in section 5.12, then remove the lower rear screen and raise the hood. Allow the machine to cool.
2. Open the radiator drain valve (1) and allow the coolant to drain into a catch container.
3. Close the drain valve, then add coolant (with SCA additive) into the radiator through the fill cap until full.
4. Warm the engine to operating temperature, then turn the engine off, remove the key and allow the machine to cool.
5. Check the coolant level, and top off (repeat steps 4 and 5 until all air has been purged and the level is full when cold).





Coolant and machine components can be HOT! Allow the machine to cool thoroughly prior to performing maintenance or service to avoid the possibility of burns.

### 7.19 Chassis Cleaning

#### Procedure

Periodic cleaning of the chassis area beneath the cab and engine compartment is also necessary to maintain safe operation. Clean as necessary. (fig. 7.19-1)



To clean the chassis/engine:

1. Shut the machine down according to the procedure in section 5.12, then remove the belly pans on the underside of the machine.
2. Raise the hood at the rear of the machine.
3. Pressure wash any debris from the engine compartment and chassis area out through the lower opening.
4. Re-install the belly pans and close the hood to complete the cleaning procedure.




If any safety signs are found to be damaged or missing after cleaning, contact your dealer for a replacement immediately. They can be reapplied according to the location illustration in section 2.3 of this manual.



When using pressurized air or water for cleaning purposes, always wear appropriate personal protection equipment to ensure your safety.

# 7 MAINTENANCE

## 7.20 Electrical System



The electrical system in RT-25 machines is equipped with fuses that help to protect the electrical components from damage. They are found in the fuse panel enclosure which is located on the left side of the engine compartment.

In the event of an electrical malfunction, check the fuse panel. Remove the fuse related to the component that is not working properly and inspect it. If it appears damaged in any way, replace it.



### 7.21 Storage

It may be necessary to store your RT-25 Compact Track Loader for an extended period of time.

Perform the following tasks to prepare the machine for storage.

#### 7.21.1 Storage Preparation

- Thoroughly clean the machine (inside and out) including the engine compartment and underbody. Open hood, remove belly pans and pressure wash to remove all buildup and debris.
- Allow machine to dry thoroughly, then reinstall belly pans, close hood. Touch up any paint blemishes to prevent rust.
- Lubricate all chassis, loader and undercarriage points as indicated on the chart in this chapter. Wipe away any excess grease.
- Replace any worn or damaged components.
- Add fuel stabilizer to near empty fuel tank, then fill to evenly distribute stabilizer throughout fuel.

---

**Note:** Run the engine for 5 minutes to circulate stabilized fuel throughout fuel system.

---

- Park the machine in a dry place that provides protection from the elements.
- Drain and refill the cooling system with 50/50 pre-mixed antifreeze/water.
- Replace engine oil and filter. (ch. 7)
- Replace hydraulic oil and filter (ch. 7)
- Jack the machine and rest the chassis on suitable mechanical supports to remove weight from the torsion axles and suspend the tracks off of the ground.
- Apply protective lubricant (grease) to all exposed cylinder rods.
- Replace air cleaner elements and a/c filter element (if equipped).
- Return all controls to neutral position.
- Cover the exhaust outlet to shield it from the elements and foreign objects.
- Disconnect and remove the battery from the machine. Adjust the electrolyte level if needed and charge before storing. Store in a warm dry place. **Do not allow battery to freeze.** Charge periodically during storage as necessary.
- Label or tag the machine to indicate storage condition.



Battery contents are flammable and corrosive. Contact with skin can cause burns! Do not smoke or allow open flame near the battery to avoid explosion! Wear appropriate PPE.

## 7 MAINTENANCE

---

### 7.21.2 Removal From Storage

Perform the following tasks to remove the RT-25 Compact Track Loader from storage and return to operating condition.

#### **Return to Operating Condition:**

- Remove protective lubricant from cylinder rods.
- Lubricate all chassis, loader and undercarriage points.
- Safely remove the mechanical supports and lower machine to the ground.
- Install fully charged battery.
- Remove exhaust outlet cover.
- Perform pre-operation checklist in chapter 5 of this manual.
- Perform starting procedure (chapter 5)
- Let engine run while observing engine monitoring systems (gauges/lights). Look for anything out of the ordinary. Should the engine temp, oil pressure or hydraulic oil temp. lights illuminate, shut the machine down immediately. Diagnose and make needed repairs before resuming operation.

### 7.22 Lifting (Jacking) Procedure

Lifting the machine should only be done from beneath the machine with a jack of the proper capacity.

#### To safely lift your machine:

1. Remove any attachments that may be fastened to the machine.
2. Install the lift arm brace as instructed in section 5.13.
3. Once the lift arms are secured, carefully exit the machine.
4. Roll or slide your jack under the front of the machine and center the lifting pad **beneath the center of the front torsion axle.**

#### **NOTICE**

**Note:** When using a jack to lift the machine, place the jack beneath the torsion axles only. Lifting at any other point may cause machine damage.

5. Once in place, jack/lift the machine upward making sure it remains stable until it has reached sufficient height to install suitable mechanical supports beneath the machine.
6. Slide the mechanical supports into place making sure they are positioned beneath the torsion axles only and spaced in such a manner that the machine will be stable when its weight rests solely on the supports.
7. Once the supports are in place, slowly lower the machine onto them and then remove the jack.

Repeat steps 4-7 at the rear of the machine should both ends of the machine need to be off of the ground for service.

Lift the machine straight up in a slow and careful manner (under the torsion axles only). Lower it this same way making sure all persons in the area are clear of the machine and its expected path.



When lifting attachments or components, use caution. Attach straps or chains securely and in such a way that they evenly distribute the weight of the item to be lifted, ensuring a balanced load. Stay clear of expected travel path.

## CALIFORNIA PROPOSITION 65

---

California (U.S.A.) state law stipulates that manufacturers of machines operated within its borders must provide a clear warning to customers regarding exposure to substances commonly associated with the machine that are recognized by the state as harmful. The manufacturer provides the following information.



**WARNING:** Cancer and Reproductive Harm - [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

0404-841